



SANDIE

User manual






Seat height adjustment



The backrest locks in three positions with an integrated lever.



Self-brake castors



for soft floor



for hard floor

Note. Self-braking chair castors initiate the integrated friction break and stop moving when the chair is unused (no weight is applied to the seat).

Other documents available for this product

Technical information for the SANDIE chair family
NARBUTAS product care guide