


MISS K

Designed by Philippe Starck, 2003


F6255007






MISS K

F6255007





01. RF6255008 — Soft fabric diffuser

02. RF11791 - Internal diffuser

03. RF28207 – Transparent Led dimmer 1004P LFP100-240V 4-150WHL




MISS K F6255007

RF6255008

SOFT FABRIC DIFFUSER ASSEMBLY






WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off. For the installation of the spare-part, it is necessary to consult a qualified electrician.

MISS K F6255007

RF6255008

SOFT FABRIC DIFFUSER ASSEMBLY



Lock the external diffuser (A) to the inner diffuser (B) by forcing (pushing) it to clicks-on.



MISS K F6255007

RF11791

INTERNAL DIFFUSER





EN

RF11791

INTERNAL DIFFUSER




Fig.1

Remove the external diffuser (A) from the internal diffuser (B).



ΕN

RF11791

INTERNAL DIFFUSER




Fig.2

Remove the lamp bulb.

MISS K F6255007

RF11791

INTERNAL DIFFUSER




Fig.3

Unfasten the 2 screws (C) inside the lamp holder (D).




Fig.4

Push through the lamp base (F) some spare electrical cable (E).

ΕN

RF11791

INTERNAL DIFFUSER




Fig.5

Extract the lamp holder (D) from the internal diffuser (B).




Fig.6

Disconnect the electrical wires (G) from the terminals (H) of the lamp holder (D).

MISS K F6255007

RF11791

INTERNAL DIFFUSER




Fig.7



Fig.8

Unfasten the screw of the cable clamp (I). Slide-off from the electrical cable (E) the lamp holder (D), lamp holder support (J) and cable clamp (I). (Fig.7)

Unfasten the internal diffuser (B) from the lamp base (F). (Fig.8)

Assemble now the new spare-part: Fasten the internal diffuser (B) on the lamp base (F). (Fig.8)

Insert through the electrical cable (E), the cable clamp (I) and the lamp holder support (J).

Connect the wires to the terminals (H) of the lamp holder (D) respecting the polarities and fasten the screw of the cable clamp (I). (Fig.7)

Insert the lamp holder (D) in his apposite position inside the internal diffuser (B). (Fig. 5 page 9)

Pull-out the excess cable (E) present inside the lamp base (F). (Fig.4 page 8)



ΕN

RF11791

INTERNAL DIFFUSER




Fig.9

Install the lamp bulb.



MISS K F6255007

RF11791

INTERNAL DIFFUSER




Fig.10

Install the external diffuser (A) on the internal diffuser (B).



MISS K F6255007

RF28207

LED DIMMER 1004P LFP100-240V 4-150WHL 4-25W



MISS K F6255007

RF28207

LED DIMMER 1004P LFP100-240V 4-150WHL 4-25W



Fig.1



Fig.2

Open the dimmer box of the damaged dimmer. For the opening, it is necessary to remove the $n^{\circ}2$ screws using a star screw driver.

Lift-up the dimmer casing from the dimmer base;

MISS K F6255007

RF28207

LED DIMMER 1004P LFP100-240V 4-150WHL 4-25W




Fig.3



Fig.4




Fig.3.1

Remove the cable clamps by unfastening the 4 screws (A) and disconnect the wires from the terminal blocks through a tiny flat headed screw driver;

Replace the dimmer and connect the wires. When connecting the wires it is necessary to respect the polarities ($L = Brown \ and \ N = Blue$) to the terminal box.

Lock the electrical cables by fastening the screws (A) of the cable clamps and make sure to block the isolation of the electrical cable.

Close the dimmer box.

It is necessary to place the casing on top and press down until it locks in.

it is necessary to insert the $n^{\circ}2$ screws using a star screw driver