

| STRIKE XL | DESIGN: ARRMET LAB 1042 |
|--------------------------------------|--|
| | Description: armchair with chromed or painted steel frame, upholstered seat and back. |
| | Use: indoor |
| | 10,5 (G) 12,5 (m ³) 0,41 ^A (H) 1 |
| | 85 47 62 62 67 180 1 2,85 7 |
| END USE | Seating suitable to furnish different areas: bars, restaurants, public spaces, libraries, conference rooms, waiting rooms but also perfect to fit into residential spaces. |
| | The frame is composed of metal tubes, round section, Ø16 mm, chromium plated (CRO) or powder coated with polyester varnish of the following colours: black (M7), white (M6) and grey brown (M8); or liquid painting, brass (OT), copper (CU) and titanium (TI). |
| COMPONENTS | Seat and backs are made of a plywood panels, padded with flame retardant polyurethane foam and upholstered with fabrics chosen by the customer. |
| | The glide plugs are made of plastic material black coloured or transparent. On request glide plugs with felted surface. |
| | Packaging is made of corrugated double wave cardboard box and protective elements. It contains 1 pc assembled. |
| CERTIFICATIONS | REACH : is the European Union regulation that addresses the production and use of chemical substances. This product contains only substances compliant with the abovementioned regulation and does not contain any "substance of very high concern" (SVHC). |
| ORDINARY CLEANING AND MAINTENANCE | Any spills should be wiped up immediately with a clean, dry cloth. Use neutral detergents only. Avoid cleaning with abrasive sponges. For further information contact the fabric suppliers printed on the material sheet downloadable from Arrmet's website. |
| EXTRAORDINARY MAINTENANCE | Supplier suggested personnel only. |
| PRECAUTIONS FOR USE | The chair must be used with its four legs resting on the floor at all times. Do not sit on the back. Do not stand on the chair. Check periodically that the screws are correctly tightened. Be careful not to sit off the seating centre. Please keep away from any heating source. The product could change the colour and shade, if exposed to direct sunlight. In case of children use, please consider the supervision of an adult. |
| | Arrmet srl is not liable for any damage that may result from the product misuse. |
| | Harmful substances This product is not toxic nor hazardous to human health, animals or environment. |
| ECOLOGY | Waste disposal Dispose this product responsibly after use at the end of its life. Please utilise the waste collection and recycling service operated by your local authority, or take it to a suitable recycling point. This products can be easily disassembled, facilitating disposal. |
| WARRANTY | 24 + 2 months as referred to in 99/44/CE European directive. |

This product datasheet comply with Italian regulation (DLgs 6th September 2005, n. 206 "Codice del Consumo"), on the subject of consumer information and implementation tool.





- A = ASSEMBLATO / ASSEMBLED
- D = DISASSEMBLATO / DISASSEMBLED
- f A = CONSUMO OTTIMIZZATO PER 2 PEZZI E MULTIPLI / USE OPTIMIZED FOR 2 PIECES AND MULTIPLE

→ VI INVITIAMO A LEGGERE LE NOTE, CONTENGONO INFORMAZIONI IMPORTANTI

ightarrow PLEASE READ CAREFULLY THE NOTES, WHICH CONTAIN IMPORTANT INFORMATION